


USER MANUAL WIRELESS SCENE SWITCH



The Eria wireless scene switch is a battery-powered dimmer for ZigBee Light link and 3.0 certified lights: it controls your preferred lighting setting.



Important note: Can be used without an Eria HUB but offers more options in combination with an Eria HUB

	short press, ON / OFF, flash green
ტ	Long press: When the paired lights ore in the operating state, the green cycle flashes and the lights are gradually turned to the darkest, but they will not go out, and then the light will frum on to the brightest. Do this until the key is released and fixed in the current brightness.
1	Short press, play the scene 1, flash green
	Long press, save the scene 1.flash green
2	Short press, play the scene 2. flash green
	Long press, save the scene 2.flash green
3	Short press, play the scene 3. flash green
	Long press, save the scene 3,flash green

ტ+1	Long press. Color loop
1+2	Long press To touch link with bulbs.
2+3	Long press Connect to the gateway.
ტ+3	Long press Reset the bulb.
1+3	Long press Reset to factory settings.

1. Pull off the lid sticking out of the battery compartment.

please visit

www.adurosmart.com/remote.





2.To use without a control station,

switch on the ZigBee lamp which





3. Touch the lamp cover with the remote and keep pressing button 1 (symbol) + button 2 (symbol) . The Eria soft white lamp will flash 2 times when it initiates the touchlink and a color lamp will flash Make sure that you keep button 1 (symbol) + button 2 (symbol) pressed



4. If the touchlink is successful the soft white lamp will flash slowly 2 times, if you have touchlinked the color lamp successful then it will turn green.



Flash 2 X





Green light




1A.Download the Adurosmart App from the Apple App Store or from Google Play or go to http://adurosmart.com/adurosmart-app/



1B.If you have a third party ZigBee compatible hub then proceed to step 9.

2.Open the Adurosmart Eria APP.







Scenes

Automations

(?) Help center Voice Assistants

(i) About & Feedback

5. On the top right corner press on the "+" symbol then press on "Add device".




6. Press on "Brands" and then select "AduroSmart ERIA".



7. Press on "Scene Controller"



8. Proceed by pressing on "Search" to allow the ERIA hub to find the remote, the LED indicator on the hub will flash green this indicates that the hub is searching for new devices.



8B. If you have a third party hub, then this is the moment to initiate the search from your Smart Home hub app.

9. While the hub is searching press and hold button 2 (symbol) and 3 (symbol) on the remote for 10 seconds if the remote is paired successfully it will be confirmed by a green flash, when the remote has failed to pair the LED indicator will flash red.



0. When the remote has been found 11. Troubleshoot and paired successfully it will show up in your search results, press on "Done" to complete the process.



If you have followed the pairing instructions but you are still not able to connect your device then follow below instructions to reset the controller.

To reset the remote:

press and hold the 1 button (symbol) +3 button (symbol on the remote simultaneously for 10 seconds

a successful reset will be confirmed by a green flash from the LED indicator, failed reset will be indicated by a red flash.



NEED HELP? CALL US

For troubleshoots, instruction video's or more information please visit us at www.adurosmart.com/faq

> Chat with one of our support agents at www.adurosmart.com

The Netherlands: +31 523687532 Support@Adurosmart.eu



www.adurosmart.com/manuals/remotesceneswitch